



## CABINET CARE

Cabinets are like fine furniture and benefit from the same degree of care. All of Canyon Creek's wood cabinets are protected with a high-performance coating that meets or exceeds KCMA industry standards. With proper care, your Canyon Creek cabinets will retain their beauty for a lifetime.

### TIPS FOR ALL CABINET TYPES

- Avoid using a dish cloth or sponge, as harsh detergent residues may harm finishes.
- Never use ammonia-based cleaners, abrasive cleaners, or soaps with dye.
- Avoid sliding objects across the cabinet surface, and use care with sharp objects—food or moisture may enter scratched surfaces and cause deterioration of the finish.
- Place small appliances so that heat/steam is directed away from cabinet surfaces.
- Never drape damp towels over cabinet doors—moisture may cause permanent damage to the finish.

### WOOD CABINETS

- Wipe spills and water spots immediately with a lint-free cotton cloth so moisture is not absorbed into cabinetry.
- For best results, use a "blotting" action rather than a wiping motion.
- When needed, use a mild detergent or soap, and warm water.
- Check around the sink and dishwasher to make sure that water and detergents do not dry on cabinet surfaces.

### PAINTED WOOD

- Clean with a mild detergent and warm water solution using a lint-free cotton cloth.
- Wipe up spills immediately with a lint-free cotton cloth so moisture is not absorbed into cabinetry.

### LAMINATE (LP & HP)

- Use a commercial counter top or laminate surface cleaner with a soft, clean cloth.
- For deeper cleaning, use an all-purpose non-abrasive bathroom cleaner with a clean, soft towel dampened in water.
- Avoid using paper towels; wood fibers in the paper may scratch the surface.

### THERMOFOIL

- Use a small amount of mild dish soap with a soft, damp cloth.
- For deeper cleaning, a 50/50 mix of water and Simple Green® may be used with a damp, soft towel.
- High heat from self-cleaning ovens can damage thermofoil—be sure to open all drawers and doors when using the cleaning cycle to avoid heat build-up.



Canyon Creek Cabinet Company  
16726 Tye St SE  
Monroe, WA 98272

P: 800-228-1830  
F: 800-787-0131

[www.canyoncreek.com](http://www.canyoncreek.com)

*See other side for more tips >>*

**CANYON CREEK**  
Cabinet Company



### HG FOIL

- Polish high gloss surface immediately after removing protective film. Products include Ultra-Gloss Superpolish, Novus 1 Polish or Plexus Plastic Cleaner, all used with a clean microfiber cloth.
- Wipe spills and splatters immediately with a soft, damp cloth. (Never use a dry cloth on foil as it may scratch the surface.)
- Use a mild soap and water mix with a damp microfiber or chamois cloth for best results.

### THERMO STRUCTURED SURFACE (TSS)

- Use mild soap and water with a soft, clean cloth; dry immediately.
- For deeper cleaning, use a small amount of mineral spirits on a clean cloth.

### ACRYLIC PANEL INSERTS

- Use a clean, soft sponge dampened with mild soap and warm water.
- Dry thoroughly, as moisture can get in between panels and damage the fabric, leaves or other organic materials used.
- Avoid glass cleaner, acetone, lacquer thinner, gritty cleansers, squeegees and paper towels.

### GLASS PANEL INSERTS

- Spray glass cleaner onto a clean cloth and wipe the glass surface.
- Avoid spraying glass cleaner directly on glass, as overspray may damage the cabinet surface.
- If glass cleaner does get on the cabinet surface, wipe immediately with a water-dampened cloth followed by a dry cloth.

### BREADBOARDS

- Breadboards come unfinished and should be oiled periodically with mineral oil or breadboard wax. Re-oil after cleaning.
- To clean, use a mild soap on a damp cloth. Do not soak the breadboard in water or wash it in the dishwasher.

### CABINET INTERIORS

- Use a solution of mild dish detergent and warm water with a clean, soft sponge.
- Dry thoroughly to avoid water seeping into seams and damaging interior surface.

### CABINET HARDWARE

- Clean with warm water and a small amount of mild dish detergent.
- Hinges may be cleaned with a cotton swab or clean cloth in detergent solution.
- Immediately dry hardware and all adjacent cabinet surfaces with a clean, soft cloth.
- Avoid harsh cleansers that may damage the hardware or the cabinet finish.



Canyon Creek Cabinet Company  
16726 Tye St SE  
Monroe, WA 98272

P: 800-228-1830  
F: 800-787-0131

[www.canyoncreek.com](http://www.canyoncreek.com)

**CANYON CREEK**  
Cabinet Company