

Cabinet Care



**Your Style
With Our Solutions
Creates Home**

CANYON CREEK
Cabinet Company

Canyon Creek offers framed and full access premium cabinet lines; a value frameless line and Closets Plus for all of your storage needs.

Our standard design options and custom capabilities provide the flexibility to design within any budget. You can order it all with fixed lead times of as little as four weeks...

Canyon Creek Cabinet Company
16726 Tye St SE
Monroe, WA 98272

P: 800-228-1830
F: 800-787-0131

www.canyoncreek.com

Cabinets are like fine furniture and benefit from the same degree of care. All of Canyon Creek's wood cabinets are protected with a high-performance coating that meets or exceeds KCMA industry standards. With proper care, your Canyon Creek cabinets will retain their beauty for a lifetime.

TIPS FOR ALL CABINET TYPES

- Avoid using a dish cloth or sponge, as harsh detergent residues may harm finishes.
- Never use ammonia-based cleaners, abrasive cleaners, or soaps with dye.
- Avoid sliding objects across the cabinet surface, and use care with sharp objects—food or moisture may enter scratched surfaces and cause deterioration of the finish.
- Place small appliances so that heat/steam is directed away from cabinet surfaces.
- Never drape damp towels over cabinet doors—moisture may cause permanent damage to the finish.

WOOD CABINETS

- Wipe spills and water spots immediately with a lint-free cotton cloth so moisture is not absorbed into cabinetry.
- For best results, use a "blotting" action rather than a wiping motion.
- When needed, use a mild detergent or soap, and warm water.
- Check around the sink and dishwasher to make sure that water and detergents do not dry on cabinet surfaces.

PAINTED WOOD

- Clean with a mild detergent and warm water solution using a lint-free cotton cloth.
- Wipe up spills immediately with a lint-free cotton cloth so moisture is not absorbed into cabinetry.

LAMINATE (LP & HP)

- Use a commercial counter top or laminate surface cleaner with a soft, clean cloth.
- For deeper cleaning, use an all-purpose non-abrasive bathroom cleaner with a clean, soft towel dampened in water.
- Avoid using paper towels; wood fibers in the paper may scratch the surface.

See other side for more tips >>



THERMOFOIL

- Use a small amount of mild dish soap with a soft, damp cloth.
- For deeper cleaning, a 50/50 mix of water and Simple Green® may be used with a damp, soft towel.
- High heat from self-cleaning ovens can damage thermofoil—be sure to open all drawers and doors when using the cleaning cycle to avoid heat build-up.

HG FOIL

- Polish high gloss surface immediately after removing protective film. Products include Ultra-Gloss Superpolish, Novus 1 Polish or Plexus Plastic Cleaner, all used with a clean microfiber cloth.
- Wipe spills and splatters immediately with a soft, damp cloth. (Never use a dry cloth on foil as it may scratch the surface.)
- Use a mild soap and water mix with a damp microfiber or chamois cloth for best results.

THERMO STRUCTURED SURFACE (TSS)

- Use mild soap and water with a soft, clean cloth; dry immediately.
- For deeper cleaning, use a small amount of mineral spirits on a clean cloth.

ACRYLIC PANEL INSERTS

- Use a clean, soft sponge dampened with mild soap and warm water.
- Dry thoroughly, as moisture can get in between panels and damage the fabric, leaves or other organic materials used.
- Avoid glass cleaner, acetone, lacquer thinner, gritty cleansers, squeegees and paper towels.

GLASS PANEL INSERTS

- Spray glass cleaner onto a clean cloth and wipe the glass surface.
- Avoid spraying glass cleaner directly on glass, as overspray may damage the cabinet surface.
- If glass cleaner does get on the cabinet surface, wipe immediately with a water-dampened cloth followed by a dry cloth.

BREADBOARDS

- Breadboards come unfinished and should be oiled periodically with mineral oil or breadboard wax. Re-oil after cleaning.
- To clean, use a mild soap on a damp cloth. Do not soak the breadboard in water or wash it in the dishwasher.

CABINET INTERIORS

- Use a solution of mild dish detergent and warm water with a clean, soft sponge.
- Dry thoroughly to avoid water seeping into seams and damaging interior surface.

CABINET HARDWARE

- Clean with warm water and a small amount of mild dish detergent.
- Hinges may be cleaned with a cotton swab or clean cloth in detergent solution.
- Immediately dry hardware and all adjacent cabinet surfaces with a clean, soft cloth.
- Avoid harsh cleansers that may damage the hardware or the cabinet finish.